

GETTING STARTED WITH PLUG AND PLAY

Activating your UTM® is easier than ever with Plug and Play. Follow these steps to easily begin the reporting cycle:

- 1. Prepare the Sensor:** verify the sensor is properly installed on the dial or inside the tank.
- 2. Connect the Sensor:** Insert the sensor cable into Port A of the UTM®. Push the connector firmly until the O-ring is fully seated against the socket lip.
- 3. Initiate Reporting:** Once connected, the sensor will automatically initiate the activation call and start the reporting process.

For optimal performance, double-check that all connections are secure before use.




Fig. 1: O-ring and Socket Lip




Fig. 2: Anova UTM®

EU031425REV05

ANOVA

Connecting the industrial world - for better.

+351 308 803 675 - PT
+44 1536 614187 - ENG
+49 631 92009006 - DE
www.anova.com

